

METAL MC RANGE

MC-SSM10 & MC-SSF10 INSTALLATION GUIDE

MC-SSM10 & MC-SSF10 Pressed Metal Clip Range

MC-SSM10



MC-SSF10


USE WITH:

#6 gauge
CSK screw

INSTALL WITH:

MC-SSCP

250 drill bit



INSTALLATION STEPS Screw fix method

- 1 Drill 25.4mm hole, 5mm deep in substrate
- 2 Insert MC-SSF10 and fix with 6G CSK screws
- 3 Insert MC-SSCP into MC-SSF10
- 4 Press in location to mark panel
- 5 Drill 2mm holes on marks
- 6 Insert MC-SSM10 and fix with three 6G CSK screws
- 7 Install panel and position panel as required
- 8 **OPTIONAL** Lock MC-SSM10 with centre 6G screw for precise installations requiring additional strength