




# LOW PROFILE LP RANGE


## LP-SM8H & LP-SMX INSTALLATION GUIDE

### LP-SM8H & LP-SMX Surface Mount Male Screw Fix – 10kg & 15kg


<p><b>LP-SM8H</b>      <b>LP-SMX</b></p> 	<p><b>USE WITH:</b></p> <p>LP-F8      LP-AF8A</p> 	<p><b>INSTALL WITH:</b></p> <p>CP-08ST      3 x #6 countersink screws</p> <p>For installation into LP-F8, follow steps 1-4 on LP-F8 install guide.</p> 
--	---	--

### INSTALLATION STEPS


- 1** Drill out 35Ø hole in substrate




- 2** Press LP-AF8A into drilled hole, fix with 3x #4 CSK screw




- 3** Fit CP-08ST into LP-AF8A



- 4** Press panel onto CP-08ST to mark clip position



- 5** Locate LP-SMX or LP-SM8H into marked position on panel, install with 3 x #6 CSK screws



- 6** Align panel and press firmly to engage clips

