

STRATLOCK SL RANGE


SL-RCF90 INSTALLATION GUIDE

SL-RCF90 How to build a wall


SL-RCF90



USE WITH:

- | | |
|---|--------------------------------|
| SL-RLE | Grub screws (supplied) |
|  | Packers if required |
| | Appropriate substrate fastener |
| | 2.5mm hex key |

Slide SL-RCF90 into groove of vertical SL-RLE and tighten grub screws with 2.5mm hex key to secure.



NOTE: Refer to Wall Layout Guide TD-15 & TD-16 for extrusion spacing instructions

Insert profile end of horizontal SL-RLE into SL-RCF90, tighten grub screws with 2.5mm hex key to secure.

