











PANELSAFE PS RANGE

PS-150E & PS-S150E INSTALLATION GUIDE

PS-150E & PS-S150E PanelSafe Easy Fit Restraint System

<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>PS-150E</p>  </div> <div style="text-align: center;"> <p>PS-S150E</p>  </div> </div>	<p>USE WITH:</p> <p>PC Standard Range LP Low Profile Range VL Very Low Profile Range MC Metal Range</p>	<p>INSTALL WITH:</p> <p>CP-01ST CT-01 CT-09 CT-07 CT-10</p> 
--	---	---


INSTALLATION STEP OPTIONS Refer to product sheets PS-150E & PS-S150E for more information

<p>1 Drill hole through support frame</p> 	<p>2 Fit PanelSafe in 10ϕ to 16.8ϕ hole</p>  <p>Glue in place</p>	<p>3 Self tapping screw in option. Drill panel on center mark 7.5mm deep.</p> 
<p>4 Screw fit PS-M with CT-10</p>  <p>Use battery drill with clutch set</p> <p>CT-10</p> <p>PS-150E self tapping male</p> <p>Use adhesive for additional strength in soft panels</p>	<p>Surface mount option</p>  <p>2 part epoxy to glue PS-S150E surface mount onto panel</p>	
<p>6 Completed installation</p>  <p>Surface mount with PS-S150E</p> <p>Drill to 16.8ϕ with CT-07</p> <p>4</p> <p>Screws in</p> <p>Self tapping with PS-150E male</p>		

PANELSAFE PS RANGE


PS-150E & PS-S150E INSTALLATION GUIDE

PS-150E & PS-S150E PanelSafe Easy Fit Restraint System




INSTALLATION STEP OPTIONS

- A** Plan view of panel from above with 4 x PanelSafe
Larger or more flexible panels may require extra PanelSafes for correct support. Each PanelSafe has a static load of 150kgs and a drop load of 10kgs.



- B** End view with panel down



- C** Plan view of small panel from above with 3 x PanelSafe

